



## Starting up Mr.Steam Display Kiosk

- 1 Ensure all components are secure.
- 2 Plug-in electrical cord
- 3 Wait until control stops blinking, go to settings
- 4 Then from Settings choose Set Time-Adjust Time and Date



- 5 Press back arrow, go to main screen and press START button.


Turn on Chroma to ensure it is working properly. There are 9 different color settings—including a slow fade and a fast changing setting.



- 6 Go to music icon



- 7 Press Bluetooth icon (next to arrow)



- 8 On smart phone or tablet go to setting/ Bluetooth



- 9 Find code that displays Mr.Steam Audio
- 10 Sync phone with AudioWizard code is ( 5555)
- 11 Press play on music and start dancing